

# Table of Contents

<b>1.</b>	<b>Preliminary Information .....</b>	<b>1</b>
1.1	What Is In This Manual? .....	2
1.2	System Overview .....	3
1.2.1	List of Standard Features .....	3
1.2.2	List of Optional Features .....	4
1.2.3	List of Network Features .....	4
1.3	Agency Approvals and Listings .....	6
1.3.1	Specific UL Requirements .....	7
1.3.1.1	Local Protected Fire Alarm Systems .....	7
1.3.1.2	NFPA 72 Central Station – Networked Digital Communicator (ZNDC) .....	7
1.3.1.3	NFPA 72 Remote Station –Networked Digital Communicator (ZNDC) .....	7
1.4	Technical Specifications .....	8
1.4.1	Power Supply .....	8
1.4.2	Battery Charger .....	8
1.4.3	Notification Appliance Circuits/24VDC Auxiliary Outputs .....	8
1.4.4	SLC Specifications .....	8
1.4.5	System and Auxiliary Relay Outputs .....	8
1.4.6	RS-485 Network .....	9
1.4.7	Communication/Printer Ports - ZSCP3/ZICP .....	9
1.4.8	Wiring Specifications and Requirements .....	10
1.4.8.1	General Specifications .....	10
1.4.8.2	SLC Wire Specifications .....	10
1.4.8.3	Network Wiring .....	11
1.4.9	Calculating Maximum Current Draw and Battery Backup Requirements .....	11
1.5	Before You Begin Installing .....	12
1.5.1	System Architecture and Overview .....	12
1.5.1.1	Adding Remote ACMs .....	12
1.5.2	Point Programming Overview .....	13
1.5.2.1	SLC Devices, Bases, and Accessories .....	13
1.5.2.2	Global Input Programming Options .....	13
1.5.2.3	System Timing Options .....	14
1.5.2.4	Input Point Programming .....	14
1.5.2.5	SLC Output Point Programming .....	14
1.5.2.6	Output Groups .....	14
1.5.3	City Box and Reversing Polarity Interface .....	15
1.5.4	System Auxiliary Relays .....	15
1.5.5	System Control Hot Keys .....	15
<b>2.</b>	<b>Installation Procedures .....</b>	<b>17</b>
2.1	What Do I Have .....	17
2.2	Installation Sequence .....	17
2.2.1	Mount Enclosure .....	19
2.2.2	Install CP3 Board .....	19
2.2.3	Mount Chassis in Enclosure .....	19
2.2.4	Connect AC Power .....	20
2.2.5	Connect Batteries .....	20
2.2.6	Install Optional ZZRM Auxiliary System Relays .....	21
2.2.7	Install Optional Modules .....	21

2.2.8	Power Limited Wire Routing .....	21
2.3	Wiring the Signaling Line Circuits (SLCs) .....	22
2.3.1	SLC Device Capacity .....	22
2.4	Sensor Base Wiring .....	22
2.5	Installing SLC Devices .....	25
2.5.1	NFPA Wiring Styles .....	26
2.5.2	Input Modules .....	29
2.5.3	XP95A Switch Monitor Module/ XP95A Priority Switch Monitor Module .....	30
2.5.4	I/O Relay – I/O Input Module* .....	31
2.5.5	Sounder Control Module .....	32
2.5.6	Sounder Base/Relay Base .....	33
2.6	CP3 Wiring Terminal Identification .....	34
2.6.1	Network Wiring .....	35
2.6.2	NAC Wiring .....	36
2.7	System and Auxiliary Relays .....	37
2.7.1	ZZRM Auxiliary Relays .....	37
2.7.1.1	Multiple ZZRM Relay Installation .....	38
2.8	Conventional Zone Input Capabilities .....	38
2.9	Printer Output Options .....	38
<b>3.</b>	<b>System Controls and Operation .....</b>	<b>39</b>
3.1	System Display and Annunciation .....	39
3.1.1	LCD Screen .....	39
3.1.2	LED Indicators .....	39
3.1.3	Panel Control Keys .....	40
3.1.4	Function Keys .....	40
3.1.5	Alphanumeric Keypad .....	40
3.2	System LED Indicators .....	40
3.2.1	Alarm .....	40
3.2.2	Trouble .....	41
3.2.3	Supervisory .....	41
3.2.4	Silenced .....	41
3.2.5	AC Power .....	41
3.2.6	Offline .....	41
3.2.7	Test Mode .....	41
3.3	Function Keys .....	41
3.3.1	Programming (PROG) .....	41
3.3.2	Status .....	42
3.3.3	Test .....	42
3.3.4	Print .....	42
3.3.5	Drill .....	42
3.3.6	Programmable Input Keys .....	43
3.4	System Operating Modes and Annunciation .....	43
3.4.1	Normal Operation .....	43
3.4.2	Trouble Operation .....	43
3.4.3	Silence Operation .....	44
3.4.4	Alarm Operation .....	44
3.4.5	Supervisory Operation .....	45
3.4.6	Program Mode Operation .....	46
3.4.7	Test Mode Operation .....	46
3.4.8	Sleep Mode .....	47

3.4.9	Watchdog Circuit Operation .....	47
3.5	Notification Appliance Circuit (NAC) Operation .....	47
3.6	Addressable Sensor Functions .....	47
3.6.1	Analog Display .....	47
3.6.2	Sensitivity Adjustment .....	48
3.6.3	Day/Night Sensitivity Adjustment .....	48
3.6.4	Alarm Test Level Measurement .....	48
3.6.5	Automatic Test Operation .....	48
3.6.6	Maintenance Alert Operation .....	48
3.6.7	Type Code Supervision .....	48
3.6.8	LED Control Operation .....	48
3.6.9	Alarm Verification Operation .....	48
3.7	Addressable Module Operation .....	49
3.7.1	Contact Monitor Module .....	49
3.7.2	I/O Module .....	49
3.7.3	Sounder Output/Sounder Control Module .....	49
3.8	Network Operation .....	49
3.9	Zeta Zone Relay Module (ZZRM) Operation .....	50
3.10	Zeta Serial and Isolated Communication Ports (SCP3 / ICP) Operation .....	50
<b>4.</b>	<b>System Programming .....</b>	<b>51</b>
4.1	Before You Begin Programming .....	51
4.1.1	Access Privilege Code (APC) .....	51
4.2	Program Menus .....	52
4.2.1	Clock .....	52
4.2.2	System .....	53
4.2.2.1	System Options .....	53
4.2.2.2	Timing .....	54
4.2.2.3	Access Privilege Codes .....	55
4.2.2.4	Edit Banner Message .....	55
4.2.3	Network .....	56
4.2.4	Configuring Inputs .....	56
4.2.4.1	Input Options .....	57
4.2.4.2	Alarm Sensitivity Levels .....	57
4.2.4.3	Input Alerts .....	57
4.2.5	Configuring System Outputs .....	58
4.2.5.1	Notification Appliance Circuits (NACs) .....	58
4.2.5.2	Zeta Zone Relay Modules (ZZRMs) .....	58
4.2.6	Point Programming .....	58
4.2.6.1	Auto-Program .....	59
4.2.6.2	Add/Remove Point .....	60
4.2.6.3	Point Location .....	60
4.2.6.4	Point Programming Options - Edit .....	60
4.2.6.5	Point Programming Options - Browse .....	61
4.2.6.6	Point Programming Options - Status .....	61
4.2.7	Output Group Programming .....	61
4.2.7.1	Browse Group .....	62
4.2.7.2	Edit Group .....	62
4.2.8	PC Communications .....	63
4.2.9	Factory Defaults .....	63

<b>5.</b>	<b>Special Application Programming and Operation</b>	<b>65</b>
5.1	Local Protective Signaling System	65
5.2	NFPA 72 Central Station	65
5.3	NFPA 72 Remote Station	65
5.4	Special Output Group Operation	65
5.4.1	Waterflow Point Programming	66
5.4.2	Supervisory Point Programming	66
5.4.3	Remote Key Reset/Silence	67
5.4.4	Floor Above/Floor Below	67
5.5	Time Control Operations	68
5.6	Program Your Own Applications	69
<b>6.</b>	<b>Networking / Serial Devices</b>	<b>71</b>
6.1	Serial Devices	71
6.1.1	Zeta Remote Display Annunciator (ZRDA)	71
6.1.2	Conventional Initiating Zone Expansion	71
6.1.2.1	ZFZA/ZTZB	71
6.1.2.2	Dual Input/Output Module	72
6.1.2.3	Panel Network Interface (ZPNI)	72
6.1.3	SLC Loop Expansion Using the ZRPC and ZACM	72
6.1.4	ZRLD Remote LED Driver	72
6.1.5	ZCBM City Box/Reversing Polarity Module	74
6.1.6	Networked Digital Communicator (ZNDC)	74
6.2	Serial Device Configuration	75
6.3	Supervision	75
6.4	Addressing Serial Devices	76
6.4.1	ZACM Addressing	76
6.4.2	ZTZB/ZFZA DIP Switch Configuration	77
6.4.3	ZRLD DIP Switch Configuration	78
6.4.4	ZRDA Addressing	78
6.4.5	ZRLD Network Addresses	79
6.4.6	ZCBM Network Addresses	79
6.4.7	ZPNI DIP Switch Configuration	80
6.5	Serial Device Technical Specifications	80
6.5.1	ZTZB/ZFZA Specifications	80
6.5.2	Power Requirement - ZRDA	81
6.5.3	Power Requirement - ZRLD	81
6.5.4	Power Requirement - ZPNI	82
6.6	Wiring Block Diagrams	82
6.6.1	Wiring Block for ZFZA/ZTZB, ZRLD Network Devices	82
6.6.2	Wiring Block for ZRPC, ZCBM, ZRDA Network Devices	83
6.6.3	Wiring Block for ZDIO Network Devices	83
6.7	Serial Device Enclosure Installation Procedures	84
6.7.1	Serial Device Enclosure Installation	84
6.7.2	Single Device Installation	84
6.7.2.1	Dual Device Installation	84
6.7.3	Installation of ZACMs	84
6.7.3.1	Adding a Second ZACM	84
	<b>Appendix A: Classic 2000 Mk II Part Number/Ordering Information</b>	<b>85</b>

<b>Appendix B: Classic 2000 Mk II Battery Backup Calculation .....</b>	<b>86</b>
<b>Appendix C-1: 24VDC Notification Circuit Compatible Devices .....</b>	<b>88</b>
<b>Appendix C-2: Two-wire ZTZB/ZFZA Smoke Detector Compatibility .....</b>	<b>89</b>
<b>Appendix C-3: Compatible SLC Devices and Accessories .....</b>	<b>90</b>
<b>Appendix D: Classic 2000 Mk II BASIC OPERATING INSTRUCTIONS .....</b>	<b>91</b>
<b>Appendix E: Classic 2000 Mk II Programming Menus .....</b>	<b>92</b>
<b>Appendix F: ZNDC Wiring Diagram .....</b>	<b>98</b>
<b>Appendix G: Input Point Record .....</b>	<b>99</b>
<b>Appendix H: Glossary of Terms .....</b>	<b>103</b>
<b>Appendix H-1: Glossary of Acronyms .....</b>	<b>104</b>
<b>Appendix I: Analog Value Conversion Table .....</b>	<b>105</b>
<b>Appendix J-1: X-Pert Card (Sensor Base) Addressing .....</b>	<b>107</b>
<b>Appendix J-2: Dip Switch Addressing .....</b>	<b>108</b>
<b>Appendix K: Printing Operation .....</b>	<b>109</b>
<b>Appendix L: Mapping Operation .....</b>	<b>110</b>